

Here are some pictures to help with the installation, you will notice in this install instead of using the crimp terminals, I simply soldered the wires across the original switch connectors. This is not the easiest method, but I prefer it because it takes up less room. The choice is yours.

